

WARNING: Read these instructions before proceeding with the installation of this Keypad or you may VOID THE WARRANTY!

LITETOUCH EURO KEYPAD INSTALLATION ADAPTER PROCEDURE

Installing the Euro Keypad Installation Adapter

Required for Euro Installation into a Standard U.S. J-Box.

1. **IMPORTANT, PLEASE READ** - When installing Standard U.S. J-Boxes, mount flush from the face of stud, rather than the traditional offset mounting (see Fig. 1 and 2).
2. Prior to cutting the drywall, attach the Euro Keypad Installation Adapter to the J-Box (see Fig. 1 and 2).
3. Closely cut the drywall around the protruding portion of the Euro Keypad Installation Adapter (see Fig. 3 and 4).

Notes:

- ◆ If a standard sized J-Box hole is cut out, after installation, the faceplate will not cover the entire hole.
- ◆ When installing a double-gang keypad a three-gang J-Box is required (see Fig. 2 and 4).

